

Convert Model LT Single Pull Cable to Dual Pull Cable Head

DO NOT remove the looped safety pin in the extinguisher head until the pull cable is installed. The extinguisher will discharge if the pin is removed prior to inserting the activation cable.

The following instructions will help you convert the Model LT single pull cable head to a Dual Pull Cable head.

INSURE THAT THE SAFETY PIN IS INSTALLED IN THE MODEL LT SINGLE PULL CABLE HEAD OR PUSH KNOB SHAFT PRIOR TO BEGINNING

Remove the single pull cable activating head from the extinguisher (See pictures on next page):

Using a 1/8 inch punch, tap out the roll pin on the discharge head. It is located to upper left of the pressure gauge. **Drive it out from the gauge side of the head. Keep the pin.** Loosen set screw # 1 – almost all the way out - on the side on the discharge head. Twist and pull the top off of the discharge head.

Note: You may have to lubricate the “O” ring on the dual cable activation head. Any general purpose grease will do.

Twist and push the new dual pull cable head top onto the valve body, it will snap into place on the discharge head.

Tap in the roll pin from the gauge side of the head – otherwise the head may loosen on the cylinder and cause a leak..

Install the extinguisher in the vehicle.

Pull Cables

Mount the pull cable handles in the desired locations. We suggest a minimum of a 12 inch bend radius for the cable.

Remove the inner wire from each pull cable and cut the outer conduit to the length required, including the amount necessary to insert the conduit into the fitting. Install the pull cable ferrule into the hole that has Insert the end of the cable conduit in the conduit fitting on the side of the discharge head.

Insert the inner cable wire through the conduit until it passes out the back side of the head. Tighten the setscrew on the top of the black slide to secure the inner wire.

Clip off excess wire flush with back of the dual pull cable head.

Ensure that the set screws, that secure the inner wire on the black slide are secure.

Snap the plastic dust cap on the top of the discharge head to prevent dirt from getting into the head.

CALIFORNIA (HEADQUARTERS)

5165-C Commercial Circle, Concord, CA 94520
Phone: 800-400-2259 Fax: 925-405-0311
email: info@safecraft.com

NORTH CAROLINA (REPAIR FACILITY)

5980 Grand National Lane, Concord, NC 28027
Phone: 704-455-9422

NO WARRANTIES, EXPRESSED OR IMPLIED ARE MADE FOR THE SUITABILITY OF THIS PRODUCT FOR ANY PURPOSE. NO WARRANTY OR REPRESENTATION IS MADE AS TO THIS PRODUCTS ABILITY TO PROTECT THE USER FROM ANY INJURY OR DEATH. THE END USER MUST DETERMINE THE SUITABILITY OF THIS PRODUCT FOR THEIR APPLICATION.



Model LT Single Pull Cable



Model LT Dual Pull Cable



Model LT10

SAFECRAFT
SAFETY EQUIPMENT

Please Visit:

www.safecraft.com

to learn more about our complete line of extinguisher systems

Convert Model LT Single Pull Cable to Dual Pull Cable Head

